Ri bristle filter

Ri-Treat and Ri-Scape filter

The Ri Bristle Filter is fitted as a standard item in our secondary treatment systems and can be incorporated with our septic tanks and holding tanks for better quality effluent.

We recommend cleaning the filter quarterly, with replacement annually or as required.

Poor maintenance or factors such as garbage disposals and excessive laundry may result in more frequent inspections/servicing or replacement of the filter.

Features

- Keeps out hair, lint, tissue, seeds and other items that can clog pumps and soakage trenches.
- Provides excellent filtration.
- Offers over 300 cubic inches of open area to reduce clogging.
- Flexible filters can be used in hard-to-reach Tees or baffles, etc.
- Made from twin 2.5mm galvanised wire with black UV-stable polypropylene bristles for superior filtration of your septic tank.

Installation and removal

To install

Push the Ri bristle filter into the top of the PVC tee inside the tank until the 90-degree wire handle touches the top of the tee. The filter is now 'installed', as shown in the picture.

To remove for cleaning or replacement

Remove the filter by pulling up on the filter handle. We recommend hosing down the filter over the inlet chamber. If replacing, put the used filter in a plastic bag for proper disposal.

To order

Please contact Ri-Industries:

Email: sales@ri-industries.com.au

Phone: 8444 8100







Ri-Industries was established 1947. We are totally committed to achieving excellence in all that we do, which is why South Australian residents and businesses repeatedly buy our products and regularly recommend us. www.ri-industries.com.au







